





1. Packard Bell / 48 Circa 1939; BC/SW



3. RCA / 4T 1936; Broadcast band; electronically restored



5. Arvin / 6555T 1952/1953; BC/SW



7. Crosley / E20 1953; Broadcast band



2. Telefunken / Gavotte 7 1956/1957; BC/SW/FM; not working



4. Crosley / E-15WE 1953; Broadcast band; works



6. Philco / 610B 1935; BC/SW



8. Peerless ? / P ? Circa 1928; Speaker



California Historical Radio Society



9. Stromberg Carlson / 1141 1948; Broadcast band; restored



11. Unico / 571-B-20-940 1940s; Broadcast band; electronically restored



13. Zenith / X405V Circa 1955; Broadcast band; works



15. Telefunken / Gavotte Circa 1956/1957; BC/SW/FM; works



10. Remler / 171 Circa 1939; Broadcast band; manufactured in San Francisco; electronically restored



12. Westone / DF4 Circa 1934; Broadcast band



14. Majestic / 5511938; Broadcast band; electronically restored



16. Garod / ? Circa 1937-1940; BC/SW; electronically restored





17. Zenith / H511F Consoltone1951; Broadcast band; electronically restored



18. Crosley / 515 Fiver 1935; Broadcast band



20. Philips (France) / BF151U 1955; BC/SW; electronically restored



22. Saba / 90/11K 1961/1962; BC/SW/FM



24. Emerson / 513 1948; Broadcast band



21. Westinghouse / H125 Little Jewel Refrigerator 1945/1947; Broadcast band



23. General Electric / H624 1939; BC/SW

19. Chanticleer / 650







25. Philco / 60 1934/1935; Broadcast band



26. RCA / 1RA33 Circa 1961; Broadcast band; electronically restored




28. Capitol Phono Hollywood / U14 Circa 1946; 78 rpm phono; electronically restored; phono working



30. RCA / X6001950ca; Broadcast band; electronically restored







27. Arvin / 417 Rhythym Baby 1936/1937; Broadcast band; electronically restored



29. Crosley / Tridyn 3-R3 1924; regenerative; has tubes



31. Marantz / 2020 AM/FM Tuner





33. Atwater Kent / 331927; TRF; Broadcast band; has tubes



35. Crosley / 516 1935/1936; Broadcast band



37. Philco / 37-660B 1936.1937; BC/SW



39. Zenith / 7S529 1940/1941; BC/SW



34. Westinghouse / H125 Little Jewel Refrigerator 1945/1947; Broadcast band



36. Delco / 1102 1935; BC/SW



38. Dynaco / 400 Stereo power amplifier



40. Brunswick / 5NO1928; Superheterodyne; broadcast band; has tubes



California Historical Radio Society



41. Radiola / 20 1925; TRF; Broadcast band



43. Zenith / 7H820 1948-49; AM/FM; AM working, FM needs service



45. Zenith / Transoceanic T-600L/6T40N 1955; BC/SW



47. Westinghouse / H125 Little Jewel Refrigerator 1945/1947; Broadcast band; electronically restored



42. Philco / 41-250 1941; BC/SW



44. American Bosch / 5A 1931; Broadcast band

-			
d <u>i</u>	-	3	
		3	
2		#	
51			

46. Setchell Carlson / 427 Frog Eyes 1947; Broadcast band; electronically restored



48. Packard Bell / ? Late 1940s; Broadcast band, 78 rpm phono







49. Philco / 60B (first version) 1933/1934; Broadcast band



50. Wards Airline / 14BR-685A 1941; BC/SW; electronically restored



52. RCA / BP-6 1946/1947; Broadcast band



54. Philco / 41-220 1941; Broadcast band



56. Grundig / SO 190U Circa 1960; BC/SW/FM; has phono; radio slightly distorted, phono works



51. Philco / 37-623B 1936/1937; BC/SW



53. Airline / 15GSE-1068 1952ca; Broadcast band; electronically restored



55. Zenith / 6D520 1941ca; Broadcast band; works



California Historical Radio Society



57. Unknown / . 1925ca; TRF



59. Zenith / H845 Super Interlude 1964; AM/FM; works



61. Stromberg Carlson / 1101 Series 13E 1946; Broadcast band



63. Sentinel / 335P 1950; Broadcast band; tube portable



58. Zenith / 7H820 1948-49; AM/FM



60. Philco / 52C 1932/1933; Broadcast band



62. Crosley / Deforest Trirdyn 1925; TRF; Broadcast band



64. Bendix / 115 1948; Broadcast band







65. Philco / 51-930 1951; Broadcast band; electronically restored



67. General Electric / 145 1948ca; Broadcast band; AC/DC



69. Airline / 62-114 1934/1935; BC/SW



71. Unknown / 1925ca Superheterodyne?



66. Truetone / D2261 1942; Broadcast band



68. Day Fan / Day Craft 5 5046 1925; TRF; Broadcast band; has tubes



70. Atwater Kent / F2? 1929; Speaker



72. Philco / 42-345 1942; BC/SW







73. Belmont / 6D121 1847; Broadcast band; electronically restored



75. Crosley / 11-100U 1951; Broadcast band; electronically restored



77. Rola / .

Horn speaker; driver has continuity



79. Sentinel / ? 1941ca; Broadcast band; electronically restored



74. Emerson / 642A 1950; Broadcast band; electronically restored



76. Airline / 74BR-1502B1947; Broadcast band; electronically restored



78. Kemper / Kompak K56 1928; Broadcast band



80. Stewart Warner / 07-513H1939; Broadcast band; electronically restored





81. American Bosch / 5051935; Broadcast band; electronically restored



83. Zenith / G2438Z1 1950; 16" BW television



85. Philips Norelco / L6X35T/54 1967; BC/LW/SW; solid state



87. Blaupunkt / Derby 95700 1964/1965; AM/FM/LW/SW; Solid state; Portable + Car radio



82. Sylvania / 512RE 1951; Broadcast band; electronically restored



84. Admiral / 909A All World 1959; BC/LW/SW; solid state



86. Automatic / 612 1946; Broadcast band



88. Viking / Junior Circa 1926; TRF; no tubes







89. General Electric / K-43 1933; Broadcast band; works



90. Zenith / 7S434 1939; BC/SW; electronically restored



92. John F. Riders / Volume I-XXIII Radio Troubleshooting Manuals



94. Scott / 800B 1946; BC/SW/FM; cabinet and electronics restored



91. Farnsworth / AC-70 1940; BC/SW; electronically restored



93. Majestic / 3441933;Broadcast band; cabinet and electronics restored



95. Zenith / 10S491 1940; BC/SW; cabinet and electronics restored